



Setting Up a New Remote or Reconnecting the Existing Remote

Note: - *The below operations should be carried out before programming, when changing to a new remote or in the event the appliance cannot be controlled by the remote:*

1. Hold the Reset Button (see below) on the appliance for 3 seconds (pen Point may needed) until you hear 3 short beeps from the unit, release the button.



2. Press the  Power button (see below) on the remote, the programming is finished when you hear 1 long beep from the appliance.



If you want the signal to change, for example if you have 2 appliances in the same room and they are operating on the same signal then you can select a different signal range by following the steps below.

3. Open the back cover of the remote control.
4. Press the Reset button on remote handset.
5. Follow the steps 1. and 2.

